



Production Use - 10 ppm daily or 100 ppm weekly

- Save money on water and labor
- Reduce water, fertilizer and fungicide leaching
- Uniform distribution of water and chemicals
- Uniform soil wet up and dry down
- Minimize edge effects

Pre-Shipment Use - 600 ppm

- Reduce wilt at retail
- Decrease plant loss at retail
- Improve profits
- Maintain better plant quality at retail





INJECTION TABLE

mL of AquaGro 2000L per Liter of Stock Solution								
Injector Ratios	PPM							
	5	10	50	100	500	750	1000	1200
1:300	1.5	3.0	15.0	30.0	150	225	300	360
1:200	1.0	2.0	10.0	20.0	100	150	200	240
1:150	0.75	1.5	7.5	15.0	75	112.5	150	180
1:100	0.50	1.0	5.0	10.0	50	75	100	120
1:50	0.25	0.5	2.5	5.0	25	37.5	50	60
1:30	0.15	0.3	1.5	3.0	15	22.5	30	36
1:15	0.07	0.15	0.75	1.5	7.5	11.3	15	18

How To Use This Table:

1. Determine parts per million (PPM) of AquaGro 2000 L you wish to inject. Find that number on the top row.
2. Find your injection ratio in left column of table.
3. The intersection of the PPM column and injection ratio row designates the number of mL of AquaGro 2000 L concentrate needed for each Liter of stock solution.

For more detailed use information call 1-800-257-7797.